

RIM PREP 101

follow these 5 steps before
powder coating



STEP 1

Dismount the tires from all rims. DIY-ers usually have the know how to do this but you can always drop by your local tire shop to get them dismounted. If you go this route, consider timing it with the replacement of your tires to save money on dismounting.

STEP 2

Remove All TPMS sensors and weights.



STEP 3

Remove the valve stems.



STEP 4

If bearings are present they will have to be removed.



STEP 5

Remove any excess grease and dirt; bring in a clean condition.

